



3/8"-16 x 1-7/8" SOCKET
BUTTON HEAD SCREWS
4 REQUIRED PER THIS STEP
(NOTE: LENGTH MAY VARY)

3/8" LOCK WASHER
4 REQUIRED PER
THIS STEP



3/8" REGULAR WASHER
4 REQUIRED PER
THIS STEP

Assembly Instructions for
items T502FSC & T502SC-
H




3/8"-16 x 3" SOCKET
BUTTON HEAD SCREWS
4 REQUIRED PER THIS STEP
(NOTE: LENGTH MAY VARY)

3/8" REGULAR WASHER
4 REQUIRED PER
THIS STEP

3/8" LOCK WASHER
4 REQUIRED PER
THIS STEP

Assembly Instructions for
items T502FSC & T502SC-
H



Assembly Instructions for
items T502FSC & T502SC-
H